


Mplayer B Voice Alarm REC & PLAY

Front panel



Rear panel


**User recordable voice messenger
message trigger by 8 dry contacts closure**
Features:

- ▶ USB, SDcard memory interface,
- ▶ Controls
Front: REC, PLAY, NEXT, BACK, MIC input and Line input for recording
Rear: Locking Switch, DRY contact closure
- ▶ Indicators
1.5" B/W Graphic LCD
- ▶ Connectors
Output : Line output with Euroblock Pitch 3.5 mm
USB & SD Card Slot

Operations:

- ▶ REC mode
Front: REC, NEXT, BACK, MIC input or Line input for recording
Press NEXT or BACK for selecting file number(USB or SD Card)
Press REC for recording to selected file number(USB or SD Card)
- ▶ PLAY mode
Front: PLAY, NEXT, BACK, USB or SD Card
Press NEXT or BACK for selecting file number
Press PLAY for playing from selected file number
Rear: Dry contact closure 1 to 8(Euroblock)
▶ Close contact point for playing continuously from selected file number
Open contact point to stop playing
Priority: USB > SD Card

LOCK mode

Rear: LOCK switch
Slide on for locking of front buttons(REC,PLAY,NEXT,BACK)
Slide off for unlocking of front buttons(REC,PLAY,NEXT,BACK)

- ▶ COPY mode
Copy from USB(or SD Card) to SD Card(or USB)
Front: USB & SD Card Slots